



Beta
motorcycles

Shark Fin Rear Brake Disc Protector

Installation instructions for
Part #AB-10389
All RR and RS Models

1. Remove the rear wheel from your Beta.
2. Remove the rear brake pad pin plug, the brake pad pin, and the rear brake pads.
3. Slide the brake caliper assembly back off the locating block of the swing arm, then separate the caliper support bracket (bottom half) from the caliper.
4. The shark fin is going to take the place of the caliper support bracket, so remove the rubber boot from the original caliper support bracket and install it in the same location on the shark fin.
5. Remove the locating pin from the caliper support bracket and install it in the same location on the shark fin. Be sure to use medium thread locking compound.
6. Before reassembling the rear brake caliper, lube up the locating pins with some quality wheel bearing grease.
7. Fit the complete shark fin together with the brake caliper by lining up the 2 locating pins with the 2 rubber boots and sliding them into one another.
8. Slide the newly assembled rear brake caliper with shark fin protector back onto the swing arm locating block.
9. Reinstall the rear wheel, and be sure to pump up your rear brake.
10. Head out and ENJOY THE RIDE

